


VIDEO PINBALL™

ATARI® GAME PROGRAM™ INSTRUCTIONS



COMPLETE
GAME PLAY
INSTRUCTIONS

PINBALL IN
YOUR OWN HOME


HELPFUL HINTS
Section 7

NOTE: Always turn the console power switch off when inserting or removing an ATARI® Game Program™ cartridge. This will protect the electronic components and prolong the life of your ATARI Video Computer System™ game.
Manual, Program, and Audiovisual ©1980, ATARI, INC.

TABLE OF CONTENTS

1. INTRODUCTION	1
2. OBJECT OF THE GAME	2
3. USING THE CONTROLLERS	3
4. CONSOLE CONTROLS	4
5. GAME VARIATIONS	5
6. SCORING	5
7. HELPFUL HINTS	7

1. INTRODUCTION



How many of you out there have always longed to be a pinball wizard? Some of you may have even spent time practicing your pinball wizardry in the local arcades. But now you've got the magic of pinball right in your own home.

VIDEO PINBALL™ has all the challenge and excitement of standard pinball games, and it doesn't have any idea what a quarter is. So not only are you going to save some money, you have the comfort and well-being of your own home. What more could a pinball

ATARI® GAME PROGRAM™ INSTRUCTIONS

enthusiast ask for? And as for you pinball wizards, don't think you can master this one lickety-split. It'll be a while before your "wiz" rating is restored and in full swing.

Just in case you're a pinball rookie, there's only one thing you need to know. You're going to love it. And you're about to find out why so many others have gone goofy with "pinball madness".

So take a deep breath, turn up the stereo, and jump right into **VIDEO PINBALL**. There's just one more thing. Better get yourself a piggy bank for all those quarters you're going to save.

2. OBJECT OF THE GAME

The object of the game is to keep the ball in play as long as possible and to score as many points as possible.

Each player starts with three balls. Every time you hit the ATARI rollover four times you get an extra ball. The extra ball is indicated by a large X at the bottom of the screen (see **Figure 1**).



Flippers Bonus Ball Plunger


Playing **VIDEO PINBALL** requires skillful control of the flippers which are located at the bottom, center of the screen. When the ball drops to the bottom of the screen, you send it back into the playfield by using the flippers. The flippers are controlled with your Joystick Controller. It's your job to guide the ball within the playfield hitting bumpers, spinners, targets, and rollovers to score points.

Figure 1

Use your Joystick Controllers to “nudge” the ball, but don’t “nudge” too much or you’ll cause a “tilt”. If you “tilt” the game, your ball

scores no more points and any extra balls earned are lost. (See **HELPFUL HINTS** to learn more about nudge and tilt.)

3. USING THE CONTROLLERS



Use your Joystick Controllers with this ATARI® Game Program™ cartridge.

Be sure the Joystick Controller cables are firmly plugged into the **CONTROLLER** jacks at the back of your ATARI Video Computer System™ game. For one-player games, use the Joystick Controller plugged into the **LEFT CONTROLLER** jack. Hold the Joystick with the red button to your upper left, toward the television screen. See Section 3 of your owner’s manual for further details.

Use the Joystick Controller to move your flippers. Move the Joystick to the right to move the right flipper up, and to the left to move the left flipper up. Move the Joystick up to move both flippers at the same time. (See Figure 2).




Figure 2

Use your Joystick Controller to start the game. Pull the Joystick down (towards you) to bring the plunger back.

Press the red controller button to release the spring and shoot the ball into the playfield.

You can also use your Joystick Controller to “nudge” or apply “body English” on the ball. “Nudge” or “body English” means forcing the ball to go in a particular direction. To do this, hold the red button down while you push the Joystick in the direction you want the ball to go. All games allow you to “nudge” the ball. (See **GAME VARIATIONS** for further explanation.)

4. CONSOLE CONTROLS

GAME SELECT SWITCH

To select a VIDEO PINBALL game, press down the game select switch.

The number of players for each game appears at the upper left corner of the television screen. The game number appears to the right of the player number. (See Figure 3 for game number and number of players.)

GAME RESET SWITCH

When you have selected the game you want to play, press down the game reset switch to start the action.

Each time game reset is pressed down the game starts over. When game play starts, the player number and the ball number appear at the top of screen to the left of the score.

DIFFICULTY SWITCHES

VIDEO PINBALL offers two difficulty levels—a and b. The a level is for expert pinball players, also known as pinball wizards. The b level game is for the beginning or novice pinball player. The a level game has two extra drain holes at the bottom of the playfield. Each VIDEO PINBALL player may choose his or her own difficulty level. In a one-player game, use the left difficulty switch. For two-player games, the left player uses the left difficulty switch; the right player uses the right difficulty switch. Difficulty levels may be changed at any time during game play.




Figure 3

5. GAME VARIATIONS

VIDEO PINBALL has four exciting game variations. There are two games for one player and two games for two players. The variations are:

GAME 1 is a one-player game. GAME 1 allows you to nudge the ball. Too much nudge will cause you to lose the ball (TILT) and any extra ball is lost. During GAME 1 the bumper values are accumulated for an entire game.

GAME 2 is a two-player version of GAME 1. Each player takes a turn with one ball at a time. The turn lasts until the ball drains. Each player's score appears at the top of the screen with each turn. The

left player is always player number one.

GAME 3 is a one-player game similar to GAME 1 except that the bumper values are not accumulated. The bumper values are reset with each new ball. GAME 3 is just a bit tougher than GAME 1. For a real challenge, try GAME 3 with difficulty level a.

GAME 4 is a two-player version of GAME 3. Each player takes a turn with one ball at a time. The turn lasts until the ball drains. Each player's score appears at the top of the screen with each turn. As in GAME 2, the left player starts the game.

6. SCORING

You score points each time your ball hits targets, bumpers, rollovers, or spinners. The scoring is fast, and you'll hear special electronic sounds as points are scored. When bonus points are scored the screen flashes. Scores are posted at the top right of the screen. In two-player games, each player's score appears with each turn. At the end of a two-player game both player's scores alternate at the top of the screen.

Points are scored as follows: (See Figure 4).

SPINNERS

1 point each time the ball hits the spinner.

BUMPERS


100 times their current value. The value inside the bumper increases each time all of the diamond shaped drop targets are knocked down.

DROP TARGETS

100 points each time a drop target is hit.

ATARI® GAME PROGRAM™ INSTRUCTIONS

ATARI ROLLOVER

100 points; after hitting the ATARI rollover four times, you receive an extra ball. Each time it rolls over, the bonus multiplier increases by one. Only one extra ball can be awarded with each turn. The number of ATARI rollovers hit is indicated at the bottom of the screen by one  for each hit.

LEFT ROLLOVER

100 points each time it rolls over. Its value increases by one with each hit. When the ball drains, you receive 1000 points for each time it has rolled over, (up to 4000 points.)


SPECIAL LIT TARGET

This target lights up for only four seconds. It is located between the two lower bumpers. Each time it is hit, the screen flashes and you score 1000 points.

The bonus multiplier is tallied at the end of a turn.

This rapid scoring is accompanied with a “whirring” sound. When you have scored one million points the score rolls over and starts again. When this happens you do not lose the additional 999999 points, they remain part of your score.

Left Rollover



Drop Targets

Atari Rollover

Spinner

Bumper

Special Lit Target

Figure 4

7. HELPFUL HINTS

TILT

Tilt is caused by nudging the ball too much. When a tilt occurs, the top portion of the television screen turns red, your flippers are frozen, you cannot score points, and eventually the ball is lost through a drain. If an extra ball was earned before a tilt, you lose it. You still retain the bonus earned from the left rollover.

NUDGE

Nudging can be very helpful in preventing a lost ball. If the ball gets too close to a drain, you can use a nudge to move the ball and prevent it from dropping down the drain. Nudge the ball by holding the red controller button down while pushing the Joystick in the direction you want the ball to go. You can

also use a nudge to help score points by nudging the ball towards a rollover or target.

BANK SHOT

Use the flippers to maneuver the ball so that it rebounds off a playfield device (bumper, rollover etc.), and then moves toward a specific target.

PLUNGER

Experiment with the plunger. Try pulling it halfway back, or all the way back, or anywhere in between. You might find you have better control over the ball with a particular plunger setting. Sometimes, a combination of plunger setting and nudging will help send the ball in the direction of the ATARI rollover.

GAME PROGRAM™ CARTRIDGE LIMITED NINETY DAY WARRANTY

ATARI, INC. ("Atari") warrants to the original consumer purchaser that your ATARI® Game Program cartridge is free from any defects in material or workmanship for a period of ninety days from the date of purchase. If any such defect is discovered within the warranty period, Atari's sole obligation will be to replace the cartridge free of charge on receipt of the cartridge (charges prepaid, if mailed or shipped) with proof of date of purchase at either the retail store where the cartridge was purchased or at one of the ATARI Regional Service Centers listed below:

Atari, Inc.
1312 Crossman Ave.
Sunnyvale, CA 94086

Atari, Inc.
5400 Newport Dr.
Suite 1
Rolling Meadows, IL 60008

Atari, Inc.
43 Belmont Dr.
Somerset, NJ 08873

Atari, Inc.
2109 East Division St.
Arlington, TX 76001

This warranty shall not apply if the cartridge (i) has been misused or shows signs of excessive wear; (ii) has been damaged by being used with any products not supplied by ATARI, or (iii) has been damaged by being serviced or modified by anyone other than an ATARI Regional Service Center.

ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, ARE HEREBY LIMITED TO NINETY DAYS FROM THE DATE OF PURCHASE. CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM A BREACH OF ANY APPLICABLE EXPRESS OR IMPLIED WARRANTIES ARE HEREBY EXCLUDED.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



A Warner Communications Company 

ATARI, INC., Consumer Division
P.O. Box 427, Sunnyvale, CA 94086